

To Install Your Intake Adapter Plate:

Place the stock 94-97 gasket in between the head and adapter plate.

Loosely install the 1 inch bolts into the seven recessed holes only.

Once they are all loosely in place they can be tightened.

Next fill the holes circled in red with RTV silicone or equivalent sealer.

Once you have filled the four lower holes with sealer you can put the 98+ intake into position. Be careful not to smear the sealer too much.

Loosely install the two 2 inch bolts into the upper right holes (through the intake manifold and through the intake adapter plate right into the threads on the head).

Loosely install the remaining six 1 inch bolts.

Tighten all of the intake manifold bolts.

Proceed to wiring up the injectors, MAP sensor, TPS sensor, and connecting the fuel lines.

